



WOVEN WALLS INSTALLATION MANUAL

Walls Your Dream



Preparation

Warning:

- Do not cut or install our products until you have read these instructions.
- Should a discrepancy occur, please contact manufactures or dealers for immediately assistance and service.

Important notes prior to installation:

1. Please examine your order and corresponding document or product label that all the products information is all correct and please check the product for defects prior to installation. And the nature of this woven vinyl wallcovering by sometime weave with bi-color yarn and it might often slight irregularities or color variation seen is not defect and if it is not acceptable, please do not install it and contact your dealer immediately.
2. We do not accept any of claim due to color variation after product has been hung. Prior to installation, draw a draft of installation plan and always follow the same direction as woven vinyl wallcovering not recommend reverse hanging. Make sure the product hanging in the same direction.

Preparation

1. A Woven vinyl wallcovering products: Our woven vinyl wallcovering products are made of Woven Vinyl Material and non-woven backing. Our product has unique design and textured look with multiple functions, such as Water- proof, Anti-bacterial, great Color-fastness to light and Easy-care. Our woven vinyl wallcovering product provide in 2m width and 25m length and as its durability, it can use for wall with good resistance of abrasion scratches and impact. Also this product is water resistance and can easy to maintain for any kind of wall decoration application.
2. Adhesives:
 - Acrylic high quality glues, ex. Henkel K188E, Mepie ECO 350 (Roll), Mapie Ultrabone ECO 800 or similar products.
 - Humid and wet areas: Polyurethane compound glues, ex. Henkel R710 or similar products.
3. Wall condition:
 - Proper surface preparation is always the key point to have a good hanging result. We recommend hanging product on different kind of wall substance are need the same condition of mirror smooth and free of flaking paint or old adhesion.
 - Monitor wall moisture levels. A wall that is not properly prepared or that has too much moisture content may not be conducive to proper adhesion.
4. If necessary, apply wall with primer or sealer according to product's manual instruction.
5. Firstly, drawing a straight vertical plumb line. Most homes have settled, and the floors and ceiling are not always "plumb". This is very important step to ensure that you hang the strips straight. And all the new wall shall repeat and drawing this plumb line again.

Hanging and Trimming Product

1. We recommend ECO BEAUTY® woven vinyl wallcovering products should be installed by professional installer. Before installation, hanging product must be allowed to adjust to a room temperature above of 15° C and the relative air humidity must be between 35% and 60% and location must be climate control.
2. Our product is pre-trimmed but however to reach better joint seam, if the trimming is necessary, we recommend that our product be table trimmed with overlapping by cut it off in 1 time and remove the extra.
3. Using "Paste the Wall" method for hanging. For this method, simply apply the paste into wall and waiting for right curing time then hanging the products.
4. Time to hang your first strip! According to your install plan, you may decide to start either from the beginning of the corner behind the door or from your room has a definite focal points such as fireplace, you want to position the first strip so that a prominent section of the design is centered over the mantel. Unbook the top of the strip and place it against the marked plumb line on the wall. Make sure you have 5-10 cm of extra product at the top and bottom for trim off. Use your hands to gently smooth the top half of the product, unbook the bottom half then using a soft smoothing tool to press product to the wall and remove any air bubble. It is best to smooth from the center to the edges in diagonal movements.
5. Repeat the balancer strip with same method. You shall match the pattern by eye level and do not overlap the strips just butt the edge. Do not over work the strip by pushing or pulling...This can stretch the product. Reposition by lifting it away from the wall and sliding into position.
6. Make sure the seam is tight by using press roller or smoothing tool.
7. Thoroughly rinse the strip with a sponge or soft cloth and clean water for any of dirt or glue leaking immediately before it getting dry.
8. Use razor knife and a trim guide to trim off any excess product at the top and bottom.

Clean Up and Final Finish

1. Use a white and damp clean cloth to wipe the product surface. Use mild/soft detergent when needed.

Care and Maintenance

A proper way to take care and maintain the product will extend the life time of wall covering products.

- Please do not damage the product by any of sharp substance by moving something.
- Wet cleaning, you may use warm water or gentle detergent cleaners (PH 7-8.5). DO NOT use acetone or polish that will damage the products.



ECO BEAUTY™ China

Bamboo Industrial Zone, Huzhou, Zhejiang Province, China

China Sales Direct: +86-572-5705325

Export Sales Direct: +86-572-5705325

China Fax: +86-572-5216088

Export Fax: +86-572-5216088

Tel.: +86-198 8317 9548

Email: Sam@theflooring.pro

Website: <https://theflooring.pro>

ECO BEAUTY™
Premium Woven Vinyl Wall Covering